

Innolumis

Maxi-Nicole

INSTALLATION MANUAL




INSTALLATIEHANDLEIDING
INSTRUCTIONS DE MONTAGE
MONTAGEANLEITUNG
ISTRUZIONI DI MONTAGGIO
INSTRUCCIONES DE MONTAJE




CAUTION, RISK OF
ELECTRIC SHOCK



IEC EN60598	IP66 IP67	IK08	220-240VAC 50-60Hz					
-----------------------	----------------------------	-------------	-----------------------	--	--	--	--	--




1.



MAX 16 METER


2.



MIN 1,0mm²
MAX 2,5mm²




2.




MIN 1,0mm²
MAX 2,5mm²




3.




4.




5.




6.



6.



7.



USE CORRECTLY RATED POWERCORD, ACCORDING TO LOCAL LEGISLATION
ALWAYS USE FERRULES WHEN CONNECTING THE POWERCORD TO THE LUMINAIRE
CHECK MARKINGS ON POWERENTRY CONNECTOR WHEN CONNECTING THE POWERCORD

PLEASE MAKE SURE TO LUBRICATE ALL NUTS/BOLTS WITH AN APPROPRIATE GREASE OR LUBRICATION. SUGGESTION: KROON OIL CERAMIC GREASE.

THE LIGHT SOURCE CONTAINED IN THIS LUMINAIRE SHALL ONLY BE REPLACED BY THE MANUFACTURER OR HIS SERVICE AGENT OR A SIMILAR QUALIFIED PERSON.

Innolumis Public Lighting B.V.

Ariane 4

3824 MB Amersfoort

the Netherlands

T +31 (0)33 760 04 34

F +31 (0)33 760 01 35

E info@innolumis.com

Innolumis

www.innolumis.com